

# **TRU BLU** *POOL RENOVATIONS*

## **REPLASTER PROCEDURES**

1. Drain pool/spa and relieve hydrostatic pressure.
2. Cut and chip out plaster around fittings, lights and beneath tile.
3. Remove any loose plaster.
4. Do a heavy acid wash.
5. Install Bond Cast and let dry overnight.
6. Remove and replace main drain covers.
7. Apply two coats of new plaster and trowel until smooth.
8. Start water to refill pool immediately.
9. Supply customer with filling and brushing instructions.